

Sordin Supreme T2/X2^{BT} INSTRUCTION

Flex Com

STEP 1

Make sure that the hearing protector is switched off and connect the communication kit to the 3.5-mm input* on the right or left cup.



STEP 2

Make sure that the guide pin and hole align.



STEP 3

Make sure the screw does not enter the thread at an angle.



STEP 4

Tighten the screw (Torx size T10) carefully with a hand tool (max 0.3 Nm).

